

Switching between the 10 M Ω and 1000 M Ω input impedance on the MX55

To obtain the 1000 M Ω input impedance:
With the meter off, hold down the RANGE button
Switch the meter on.

If the meter says 10 M Ω switch the meter off.

Hold down the RANGE button
Switch the meter on
The meter should say 1000 M Ω .

You repeat these steps in order to toggle between these two choices. Normally, you will want the 10 M Ω input impedance but sometimes it is important to have the higher input impedance so you will need to know how this is accomplished. Using this higher setting, however, increases noise and is not always desirable.

